

Cleaning Manual

Roof Windows

Cleaning the Window

- Rotate sash 180° to clean outer pane.
- Secure the sash in place using the locking bolt - ensuring both hands are free for safety.
- Clean the pane using a soft, clean cloth/chamois or non-metal squeegee.
- Clean water will be sufficient for cleaning the pane.
- In hard water areas add a small amount of detergent to soften the water or wipe off all excess water after cleaning.



WARNING

- Avoid using silicone.
- Avoid using cleaning products containing abrasive particles.
- Do not use chemical products.
- Avoid wearing jewellery or sharp objects whilst cleaning.
- To prevent further damage protect the pane with clean plastic until cleaning has finished.



Keylite Ryder Close, Cadley Hill Industrial Estate, Swadlincote,
South Derbyshire DE11 9EU
T: +44 (0) 1283 200 150 F: +44 (0) 1283 223 352 E: info@keyliteuk.com

Keylite Derryloran Industrial Est, Sandholes Road, Cookstown,
Co. Tyrone BT80 9LU
T: +44 (0) 28 8675 8921 F: +44 (0) 28 8675 8923 E: info@keylite.co.uk

www.keylitteroofwindows.com

